

NOTE: The maintenance intervals listed are for vehicles operating under normal driving, road, and climatic conditions. More frequent attention may be necessary if the vehicle is subject to routine stop & go driving, extreme temperatures, dusty conditions, off-road driving, or frequent trailer towing. Consult your Land Rover Retailer for more information.

SERVICE	Miles x 1000 Years	Maintenance Interval – whichever occurs first (based on expected vehicle display).									
		16	32	48	64	80	96	112	128	144	160
		1	2	3	4	5	6	7	8	9	10
Change engine oil and replace filter		●	●	●	●	●	●	●	●	●	●
Reset the Service Interval Indicator		●	●	●	●	●	●	●	●	●	●
Reset engine oil level indicator		●	●	●	●	●	●	●	●	●	●
Check operation of all lights, warning indicators and horn		●	●	●	●	●	●	●	●	●	●
Check operation of front/rear wiper washer systems		●	●	●	●	●	●	●	●	●	●
Check condition and security of seats and seat belts		●	●	●	●	●	●	●	●	●	●
Replace pollen filter		●	●	●	●	●	●	●	●	●	●
Check condition of wiper blades		●	●	●	●	●	●	●	●	●	●
Check operation of all door checks, hood latch, and fuel flap; lubricate door checks			●		●		●		●		●
Check battery condition; check / top up electrolyte level		●	●	●	●	●	●	●	●	●	●
Check / top up fluid levels (brake, coolant, windshield washer)		●	●	●	●	●	●	●	●	●	●
Check specific gravity of coolant			●		●		●		●		●
Use SDD to check DEF level (Td6)		●	●	●	●	●	●	●	●	●	●
Drain DEF tank if vehicle has covered less than 16,000 miles in 2 years (Td6)			●		●		●		●		●
Top up DEF tank (Td6)		●	●	●	●	●	●	●	●	●	●
Drain fuel filter sedimentor (Td6)		●	●	●	●	●	●	●	●	●	●
Clean debris from auxiliary oil coolers		●	●	●	●	●	●	●	●	●	●
Check condition of drive belt(s)		●	●	●	●	●	●	●	●	●	●
Change brake fluid: every 3 years				●			●			●	
Change engine coolant: every 10 years											●
Replace spark plugs						●					
Replace air cleaner element(s) (Td6)			●		●		●		●		●
Replace air cleaner element(s) (3.0L SC V6)					●				●		

SERVICE	Miles x 1000 Years	Maintenance Interval – whichever occurs first (based on expected vehicle display).									
		16	32	48	64	80	96	112	128	144	160
		1	2	3	4	5	6	7	8	9	10
Replace primary drive belt											•
Replace secondary/supercharger drive belt (3.0L SC V6)									•		
Replace front and rear camshaft timing belts (Td6)								•			
NOTE: Remove all road wheels before inspecting brake components.											
Inspect brake pads for wear, calipers for leaks, and discs for condition		•	•	•	•	•	•	•	•	•	•
Check operation of electronic parking brake		•	•	•	•	•	•	•	•	•	•
Adjust park brake shoes		•	•	•	•	•	•	•	•	•	•
Inspect tire pressures, condition, and tread depth		•	•	•	•	•	•	•	•	•	•
Inspect exhaust system for leaks, security and damage			•		•		•		•		•
Inspect for fluid leaks			•		•		•		•		•
Inspect condition of driveshafts, suspension, and steering boots/gaiters			•		•		•		•		•
Inspect steering rod ball joint fixings, condition of ball joints and dust covers, and EPAS water drain valve			•		•		•		•		•
Inspect fuel, brake, hydraulic, and fluid pipes, hoses and unions			•		•		•		•		•
Inspect electrical harnesses, routing and connections			•		•		•		•		•
Check for free play in all suspension and body mounting bushings			•		•		•		•		•
Check condition of removable tow bar (where fitted)		•	•	•	•	•	•	•	•	•	•
Replace all flexible brake hoses: every 6 years							•				
Change transmission fluid and filter											•
Change fuel tank filter (3.0L SC V6)											•
Change fuel filter element (Td6)		•	•	•	•	•	•	•	•	•	•
Change front and rear axle oil (non-locking differential)											•
Change rear locking differential oil						•					•
Change transfer case oil; replace drain and fill plugs and washers						•					•
Conduct road test; select LOW range gears and drive the vehicle 3 – 4 vehicle lengths, then reselect HIGH range gears		•	•	•	•	•	•	•	•	•	•
If fault lamps are illuminated, interrogate with JLR-approved diagnostic tool and report findings		•	•	•	•	•	•	•	•	•	•
Check for and complete all outstanding Recalls or Service Actions		•	•	•	•	•	•	•	•	•	•